

LED INDICATORS AND ACCESSORIES



Status indicators are an essential part of the emergency system as they serve as a visual indicator to the functionality of the emergency system.

Offered in a variety of different lengths and types to suit your installation. From superbright indicator for exterior installations, to projection indicators for installation behind most opalescent diffusers.

INDICATOR CODES

LED INDICATORS



Inverter Type	Part No.	Description
BASIC	10-98-0008	LED INDICATOR GREEN SUPERBRIGHT—500MM JST EHR 2POLE
	10-98-0012	LED INDICATOR GREEN STANDARD—500MM JST EHR 2POLE
	10-98-0015	LED INDICATOR GREEN SUPERBRIGHT—1000MM JST EHR 2POLE
	10-98-0020	LED INDICATOR GREEN PROJECTION—1000MM JST EHR 2POLE
SELF-TEST & DALI	10-98-0003	LED INDICATOR RED/GREEN SUPERBRIGHT—500MM JST EHR 3POLE
	10-98-0004	LED INDICATOR RED/GREEN SUPERBRIGHT—1000MM JST EHR 3POLE
	10-98-0011	LED INDICATOR RED/GREEN STANDARD—1000MM JST EHR 3POLE
	10-98-0013	LED INDICATOR RED/GREEN PROJECTION—500MM JST EHR 3POLE
	10-98-0014	LED INDICATOR RED/GREEN PROJECTION—1000MM JST EHR 3POLE
	10-98-0018	LED INDICATOR LP RED/GREEN SUPERBRIGHT—450MM JST EHR 3POLE

INDICATOR ACCESSORY CODES

INDICATOR HOLDERS



Part No.	Description	Recommended Hole Diameter	Panel Thickness
10-95-0001	LED INDICATOR HOLDER PANEL PLASTIC—BLACK—RTC-51	6.5mm	1.0mm

INDICATOR BEZEL



10-95-0002	LED INDICATOR HOLDER—CEILING TILE	18mm	5 – 20mm
------------	-----------------------------------	------	----------

CONTACT US

Lux Box Lighting Technology Limited

1 WYMANS WAY, FAKENHAM, NORFOLK, NR21 8NT

☎ 03300 539 339 ✉ sales@luxbox.co.uk 🌐 luxbox.co.uk